

km 15,142

Diagram illustrating the layout of a road cross-section, showing the relationship between the road edge, the communication axis, and the travel lane.

- Hranice nebezpečného pásma** (Boundary of the danger zone) - Indicated by a black line.
- Hranice rozhledového pole dle čl. 7.3.4 a 7.4.3 ČSN 73 6380** (Boundary of the field of vision according to articles 7.3.4 and 7.4.3 of ČSN 73 6380) - Indicated by a red dashed line.
- Osa komunikace** (Communication axis) - Indicated by a blue line.
- Osa jízdního pruhu** (Travel lane axis) - Indicated by a green line.

Sokolnice-Telnice - Brno-Chrlice

PS 32-01-11 Sokolnice-Telnice, SZZ

SITUACE PŘEJEZDU P7183 (M 1 : 250)

102