

17	PANEL SVORKOVNIC																																																																		
16	<table border="1"> <tr> <td>Px</td><td>HP</td><td>SP</td><td>SP</td><td>ZP</td><td>PD</td><td>R</td><td>S</td><td>T</td><td>RST</td><td>ZxH</td><td>SKP</td><td>ZS</td><td>ZD</td></tr> <tr> <td>*1</td><td>*1</td><td>*1</td><td>*1</td><td>*1</td><td>*1</td><td>*1</td><td>*1</td><td>*1</td><td>*2</td><td>*2</td><td>*2</td><td>*2</td><td>*2</td></tr> <tr> <td>01</td><td>02</td><td>03</td><td>04</td><td>05</td><td>06</td><td>07</td><td>08</td><td>09</td><td>10</td><td>11</td><td>12</td><td>13</td><td></td></tr> </table>													Px	HP	SP	SP	ZP	PD	R	S	T	RST	ZxH	SKP	ZS	ZD	*1	*1	*1	*1	*1	*1	*1	*1	*1	*2	*2	*2	*2	*2	01	02	03	04	05	06	07	08	09	10	11	12	13		PANEL SVORKOVNIC											
Px	HP	SP	SP	ZP	PD	R	S	T	RST	ZxH	SKP	ZS	ZD																																																						
*1	*1	*1	*1	*1	*1	*1	*1	*1	*2	*2	*2	*2	*2																																																						
01	02	03	04	05	06	07	08	09	10	11	12	13																																																							
15					01	02		03		04		05		06		07		08		09		10		11		12				Panel TP																																					
14					52 CANI				39 CANO				CANI				CANO				REZ				REZ																																										
13					A		B		A		B		A		B		A		B		A		B		A		B		VANA 144TE																																						
12	MP				VN				BN				1DMS												TPDJ								Panel v.v.																																		
	NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				-EP												NMS1-2000																																										
	01				02				03				04				05				06				07				08																																						
11	01		02		03		04										12		13										15		16		17		18		19		20		Panel jističů																										
	C/4A/2C		4A/2C		C/1A/2C		2A/2C										1A		1A										2A		0,5A		0,5A		2A		0,5A		2A																												
	+/-TPA		+/-TPB		+/-E		+/-										Px/ZxH1		Px/ZxH2										DMS-INDMS-OUT1K		1P		5K		5P																																
10													10		11		12		13		14		15		16		17		18		19		20		21		22		23		24		25		Panel pojistik																						
													0,16A0		16A0		16A0		16A0		16A0		16A0		16A0		16A0		16A0		16A0		16A0		16A0		16A0		16A0		16A0																										
													SŽ		SZ		SČ		SB		SŽ2		PrSŽ		PrSZ		L1ZL		1ČL		1BL		2ZL		2ČL		2BL		2Ž2		Se1BS		Se1M																								
09	1BS				1DTR				5BS				5DTR								BCD-PS				BCD-BA				BCD-BV				Panel v.v.																																		
	RZ3A								RZ3A												NMŠ1-2000				NMŠ1-2000				NMŠ1-2000																																						
	01				02				03				04				05				06				07				08																																						
08	1KP				1KM				1SP				1SM				5KP				5KM				5SP				5SM				Panel v.v.																																		
	NMŠ1-2000				NMŠ1-2000				NMPŠ1-2000				NMPŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMPŠ1-2000				NMPŠ1-2000																																						
	01				02				03				04				05				06				07				08																																						
07	Se2M				S1-2M				Se3M				L1-2M				Se1-BS				Se1-MS				Se1-BP				Se1-MP				Panel v.v.																																		
	NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ2-60				NMŠ2-60				NMŠ1-2000				NMŠ1-2000																																						
	01				02				03				04				05				06				07				08																																						
06	2PSS				2PSP□				2PDO				2PVO				2HO				5R				5OP				5OM				Panel v.v.																																		
	NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000																																						
	01				02				03				04				05				06				07				08																																						
05	1PSS				1PSP□				1PDO				1PVO				1HO				1R				1OP				1OM				Panel v.v.																																		
	NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000																																						
	01				02				03				04				05				06				07				08																																						
04	L1-ZP				L1-ČP				L1-BP				L2-ZP				L2-ČP				L2-BP				L2-Ž2P				L1-KBP				Panel v.v.																																		
	NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000				NMŠ1-2000																																						
	01				02				0																																																										