

ROZMĚRY SKŘÍNÍ BGT

Pohled na panel BGT06-126TE zepředu

ABP1 5KJ				ABP2 3KJ				ABP3 1KJ				ABP4 V1-2				ABP5 V3										
4TE	9TE	VPPB3 VPPB10 <div></div>	4TE	4TE	4TE	9TE	VPPB4 VPPB8 <div></div>	4TE	4TE	4TE	9TE	VPPB5 VPPB9 <div></div>	4TE	4TE	4TE	9TE	VPPB2 VPPB6 <div></div>	4TE	4TE	4TE	9TE	VPPB1 <div></div>	4TE	4TE	Krycí plech REZ	
5KJ				3KJ				1KJ				V1-3J				LKJ				VPPB1						
VPPB3 VPPB10				VPPB4 VPPB8				VPPB5 VPPB9				VPPB2 VPPB6				VPPB1										
SIC006 GS01	ACB119 GS04	IMC003 GS03	IMC003 GS03	SIC006 GS01	ACB119 GS04	IMC003 GS03	IMC003 GS03	SIC006 GS01	ACB119 GS04	IMC003 GS03	IMC003 GS03	SIC006 GS01	ACB119 GS04	IMC003 GS03	IMC003 GS03	SIC006 GS01	ACB119 GS04	IMC003 GS03								

Pohled na panel BGT06-126TE zezadu

ABP5 LKJ				ABP4 V1-3J				ABP3 1KJ				ABP2 3KJ				ABP1 5KJ							
				ABP002-2				ABP002-2				ABP002-2				ABP002-2							
				IMC vstup				IMC vstup				IMC vstup				IMC vstup							
				ACB vstup/vystup				ACB vstup/vystup				ACB vstup/vystup				ACB vstup/vystup							
				ST1				ST1				ST1				ST1							
				ST6				ST6				ST6				ST6							
				DOUBLE OUT				DOUBLE OUT				DOUBLE OUT				DOUBLE OUT							
				TRIPLE OUT/DEACT IN				TRIPLE OUT/DEACT IN				TRIPLE OUT/DEACT IN				TRIPLE OUT/DEACT IN							
				DOUBLE IN				DOUBLE IN				DOUBLE IN				DOUBLE IN							
				DEACT OUT				DEACT OUT				DEACT OUT				DEACT OUT							
				END V+				END V+				END V+				END V+							
				RS232C				RS232C				RS232C				RS232C							
				END V-				END V-				END V-				END V-							