

19	Svorkovnicový panel																																
18	Svorkovnicový panel																																
17	LK-JQ1				V1-2JQ1				V3-JQ1				VK1-JQ1								V1-2JQ2				1,2J-JQ2				3J-JQ2				panel volné vazby
	TN1-1600				TN1-1600				TN1-1600				TN1-1600								TN1-1600				TN1-1600				TN1-1600				
	01	+)			02	+)			03	+)			04	+)			05	+)			06	+)			07	+)			08	+)			
16	1K-JQ1				3K-JQ1				5K-JQ1				V7-JQ1				V8-JQ1				V3-JQ2				V8-JQ2				V1-2JQ3				panel volné vazby
	TN1-1600				TN1-1600				TN1-1600				TN1-1600				TN1-1600				TN1-1600				TN1-1600				TN1-1600				
	01	+)			02	+)			03	+)			04	+)			05	+)			06	+)			07	+)			08	+)			
15	V9-10JQ1				6-JQ1				SK-JQ1				10-JQ1				6-JQ2				V9-10JQ2												panel volné vazby
	TN1-1600				TN1-1600				TN1-1600				TN1-1600				TN1-1600				TN1-1600												
	01	+)			02	+)			03	+)			04	+)			05	+)			06	+)			07				08				
14	1 NPV				3 NPV				2-4 NPV				7-9 NPV				8 NPV				9 NPV												panel volné vazby
	TN1-1600				TN1-1600				TN1-1600				TN1-1600				TN1-1600				TN1-1600												
	01	+)			02	+)			03	+)			04	+)			05	+)			06				07				08				
13																																	panel volné vazby
	01				02				03				04				05				06				07				08				
12																																	panel volné vazby
	01				02				03				04				05				06				07				08				
11			51	240R				61	240R				71	240R				81	240R				91	240R		panel upr.							
		52	240R				62					72	240R				82	240R				92	240R										
		53	240R				63	240R				73	240R				83	240R				93											
10	01	02	03	04	05	06	07	08	09	10	11	12	13	14		16	17	18	19	20	21	22	23	24	25	pojistky							
	2A															0,5A	0,5A	0,5A	0,5A	0,5A	0,5A	0,5A	0,5A	0,5A									
	+	-														LK	V1-2	V3	Vk1		V7	1K	3K	5K	V8		V9-10	V6	SK	10			
09																									panel upravený								
08																									panel volné vazby								
07	LK-J				V1-2J				V3-J				Vk1-J												panel měření								
	1K-J				3K-J				5K-J				V7-J				V8-J																
	V9-10J				6-J				SK-J				10-J																				
06	LK-J				V1-2J				V3-J				Vk1-J												panel DSŠ								
	EFCP2 75Hz NMS1-2000				EFCP2 75Hz NMS1-2000				EFCP2 75Hz NMS1-2000				EFCP2 75Hz NMS1-2000																				
	01				02				03				04				05																
04	1K-J				3K-J				5K-J				V7-J				V8-J								panel DSŠ								
	EFCP2 75Hz NMS1-2000				EFCP2 75Hz NMS1-2000				EFCP2 75Hz NMS1-2000				EFCP2 75Hz NMS1-2000				EFCP2 75Hz NMS1-2000																
	01				02				03				04				05																
02	V9-10J				6-J				SK-J				10-J												panel DSŠ								
	EFCP2 75Hz NMS1-2000				EFCP2 75Hz NMS1-2000				EFCP2 75Hz NMS1-2000				EFCP2 75Hz NMS1-2000																				
	01				02				03				04				05																
01																																	

+) - redukce rel. (č.v.71505a) Zásuvka (č.v.71190 DS1)

ŽST. VELKÉ PAVLOVICE

Obsazení stojanu 22

928/4