

19	21-1801	21-1802	21-1803	21-1804	21-1805	21-1806	21-1807	21-1808	21-1809	21-1810	21-1811	21-1812	21-1813	21-1814	22-1815	22-1816	panel svorkovnic 80 361a
01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16		
18	22-1801	22-1802	22-1803	22-1804	22-1805	22-1806	22-1807	22-1808	22-1809	22-1810	22-1811	22-1812	22-1813	22-1814	22-1815	22-1816	panel svorkovnic 80 361a
01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16		
17	11-1801	11-1802	11-1803	11-1804	11-1805	11-1806	11-1807	11-1808									panel svorkovnic 80 361a
01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	23-1816	
16	1J-NKJ KJ41	2J-NKJ KJ41	3J-NKJ KJ41	4J-NKJ KJ41	3BLJ-NKJ KJ41												Police oboustr. 72482c
15	1J-NT MKO-2	2J-NT MKO-2	3J-NT MKO-2	4J-NT MKO-2	3BLJ-NTKJ MKO-2												
01	02	03	04	05													
14	1J EFCP-2	2J EFCP-2	3J EFCP-2	4J EFCP-2	5BLJ EFCP-2												panel relé DSS 72568
13	01	02	03	04	04												— —
11	TR POBS-2	1J-RT NT41	2J-RT NT41	3J-RT NT41	ASE-2	5BLJ-RT NT41											police oboustr. 72645a
01	02	03	04	05	06	07	08										
10	PK1ZK1 PK1ZK1 PK1ZK1 PK2ZK2	51 40Ω/0,5A	61 40Ω/0,5A	71 40Ω/0,5A	Panel DSS 72635a	Panel svorkovnic WK00											
01	02	03	04	05	06	07	08										
05	01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	
04	01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	
03	01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	
02	01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	
01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	01	
																	lišta uzemňovací 72 512 Ds6
																	Volný prostor
																	Lišta přípoňovací 80 320 Ds2

pohled zepředu

Nemilany RD PZS km 96,103	2511
Pohled na stojan 11 (KS)	