

PŘEHLED RELÉ										STOJAN:			
TYP	OZNAČENÍ	UMÍSTĚNÍ		POUŽITO NA VÝKRESE ČÍSLO									
		PATRO	POLE	VINUTÍ	13-11-12	23-21-22	33-31-32	43-41-42	53-51-52	63-61-62	73-71-72	83-81-82	
DSŠ-12P	1J ↑	08	1	41		42							
KJ-41, RT	1J-RT		2	41									
			3										
			4										
KJ-41, RT	2J-RT		5	41									
DSŠ-12P	2J ↑		6	41	52	42							
NMŠ1-2000	KMH ↑	07	1	29	29	29	29	29	29	29	29	29	
NMŠ1-2000	KMZ ↑		2	29	29			22		22		52	
NMŠ1-2000	KMHO ↑		3	29				22		22		52	
NMŠM1-1500	PSR ↑		4	21		21		21		52			
NMŠ1-2000	4Jo ↑		5	42	23	42	52	21		42	42	42	
			6										
			7										
			8										
DSŠ-12P	3J ↑	05	1	41		42							
KJ-41, RT	3J-RT		2	41									
			3										
			4										
KJ-41, RT	4J-RT		5	41									
DSŠ-12P	4J ↑		6	41		42							
Kazeta	Čas.jednotka	04	1	21/26									
Kazeta	Čas.jednotka		2										
NMŠ2-4000	KZDI ↑		3	22		42		42					
NMŠ2-4000	TPSR		4	21		21							
NMŠ2-4000	TA ↑		5	21		21		21					
PT270024	PCJ ↑		61	26	22								
NMŠ1-2000	TOD-B		7	42	21	22	42 <sup>23</sup>	23	21	42	22	42 <sup>52</sup>	
NMŠ1-2000	DK-B		8		21	22	23	22	42	21	42	52	
čv. 71972b	HNB	16	4	22				22		52		22	
tlačítko	tl. HNB		5	22	22								
pojistky HNB		15	6	22									
			7										

PŘEHLED RELÉ										STOJAN:		
TYP	OZNAČENÍ	UMÍSTĚNÍ		POUŽITO NA VÝKRESE ČÍSLO								
		PATRO	POLE	VINUTÍ	13–11–12	23–21–22	33–31–32	43–41–42	53–51–52	63–61–62	73–71–72	83–81–82
NMŠM1–1500	AJ ↑	14	1	21	21	21	21	21	23	23	52	
NMŠM1–1500	AS		2	21	21	21		23	21			
NMŠM1–1500	BS		3	21	21	21		23	21			
NMŠM1–1500	BJ ↑		4	21	21	21	21	21	23	23	52	23
NMŠ1–2000	X		5	21	21	21	23	22			52	21
NMŠ1–2000	D		6	21	21	21	23	22	52	21	22	21
			7									
	↑		8									
NMŠM1–1500	SR ↑	13	1	21	21	24	23	24	24,52	23	22	23
NMŠ1–2000	KZ ↑		2	23	22	22				23		23
NMŠ1–2000	OZ ↑		3	21	23	24	23	24	21		22	23
NMŠ1–2000	UZ		4	21		22	22				22	
NMŠ1–2000	TO		5	22		21		21,52	22	23	22	23
NMŠ2–3500	TZ ↑		6	22		21		42		52		42
NMŠ2–4000	PR ↑		7	22		23						22
NMŠM1–1500	K1		8	23		24	23	22	23	23	23	23
NMŠ1–2000	SO	12	1	23	24	24		23	23	22		52
NMŠ1–0,25/0,7	SA		2	24	24	24	24	24	23	23	22	52
NMŠ1–0,25/0,7	SAN		3	24		24	(24)	(24)	23	23		52
NMŠ1–0,25/0,7	SB		4	24	24	24	24	24	23	23	22	52
NMŠ1–0,25/0,7	SBN		5	24		24	(24)	(24)	23	23		52
NMŠ1–0,25/0,7	SC		6	24	24	24	24	24	23	23	22	52
NMŠ1–0,25/0,7	SCN		7	24		24	(24)	(24)	23	23		52
NMŠ1–2000	K2		8	23	24		24				23	23
NMŠ2–4000	VXV	11	1	21		22		22		21		52
NMŠM1–1500	SP ↑		2	23		25		52		25		25
NMŠ1–2000	T3.JRJo 1Jo ↑		3	42	23	42	52	21		42	42	42
NMŠ1–2000	2Jo ↑		4	42	23		52	21		42	42	42
NMŠ1–2000	3Jo		5	42	23		42	21		42	42	42
NMŠ1–3,4	S		6	25	25		25					
NMŠ1–2000	P ↑		7	25	25	25	25	25	25	25	22	52
NMŠ1–2000	PRX ↑		8	22		23	22					52