

11	PANEL SVORKOVNIC WAGO (zezadu)																			
10	PANEL SVORKOVNIC WAGO (zezadu)																			
09	PANEL SOUČÁSTEK																			
08	A	B	A	B	A	B														
	CAN I		CAN O		CAN O															
	01	02	03	04	05	06														
07	±TPA	±TPB	±E	+/-	OTPA	OTPB											TRS	WPNQ		
	C4/2	C4/2	C1/2	C1/2	C2	C2											*	*		
	01	02	03	04	05	06											17	18		
06	S1-Z	S1-Č	S1-B	S2-Z	S2-Č	S2-B	S2-Ž	S3-Z	S3-Č	S3-B	S3-Ž		Se1-B	Se1-M	Se2-B	Se2-M	Se3-B	Se3-M		
	0,16A	0,16A	0,16A	0,16A	0,16A	0,16A	0,16A	0,16A	0,16A	0,16A	0,16A		0,16A	0,16A	0,16A	0,16A	0,16A	0,16A		
	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18		
05	L-Ž	L-Z	L-Č	L-B	L-Ž2	PřL-Ž	PřL-Z													
	0,16A	0,16A	0,16A	0,16A	0,16A	0,16A	0,16A													
	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18		
04	BN KS --- --- ---	Un	KRYCÍ PANEL																	
			12	13	14	15	16	17	18											
			K-OC A	K-OC A	NDC A	NDC B			-ES											
	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18		
03	Se1-BP	Se1-BS	Se1-MP	Se1-MS	Se3-BP	Se3-BS	Sv	Se2-BP	Se2-BS	Se2-MP	Se2-MS	Se3-MP	Se3-BS	L-KŽP	PřL-KŽP	S1-KBP	S2-KBP	S3-KBP	Un	
	01	02	03																	
02	S1-ZP	S1-ZS	S1-ČP	S1-ČS	S1-BP	S1-BS	Sv	S2-ZP	S2-ZS	S2-ČP	S2-ČS	S2-BP	S2-BS	S3-ZP	S3-ZS	S3-ČP	S3-ČS	S3-BP	S3-BS	Sv
	01	02	03																	
01	L-ŽP	L-ŽS	L-ZP	L-ZS	L-ČP	L-ČS	Sv	L-KBP	L-BS	L-Ž2P	L-Ž2S	S2-Ž2P	S2-Ž2S	PřL-ŽP	PřL-ŽS	PřL-ZP	PřL-ZS	S3-Ž2P	S3-Ž2S	Sv
	01	02	03																	