

19	KS2-1901	KS2-1902	KS2-1903	KS2-1904	52-1905	KS1-1906	KS1-1907	KS1-1908	51-1909	51-1910	51-1911	52-1912	52-1913	52-1914	52-1915	KS2,52-1916	51-1908	KS1-1905	18	19	20	21	22	23	panel svorkovnic 80 356b
18																									
17	L1KJ		L1KR		V1,3J		V1,3R		V2J		V2R		V4J		V4R		panel volné vazby 80 363b								
	NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000										
	01	D1 *	02		03	D1 *	04		05	D1 *	06		07	D1 *	08										
16	V5,6J		V5,6R		2KJ		2KR		4KJ		4KR		V7J		V7R		panel volné vazby 80 363b								
	NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000										
	01	D1 *	02		03	D1 *	04		05	D1 *	06		07	D1 *	08										
15	V8J		V8R		V9,10J		V9,10R		1KJ		1KR		L1K-2KP		4K-1KP		panel volné vazby 80 363b								
	NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000										
	01	D1 *	02		03	D1 *	04		05	D1 *	06		07	D1 *	08	D1 *									
14	3KJ		3KR		5KJ		5KR		2aKJ		2aKR		4aKJ		4aKR		panel volné vazby 80 363b								
	NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000										
	01	D1 *	02		03	D1 *	04		05	D1 *	06		07	D1 *	08										
13	6aKJ		6aKR		V17,21J		V17,21R		V15J		V15R		V18,19J		V18,19R		panel volné vazby 80 363b								
	NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMPŠ1-2000		NMS1-2000		NMS1-2000		NMS1-2000										
	01	D1 *	02		03	D1 *	04		05	D1 *	06		07	D1 *	08										
12	5bKJ		5bKR		V25,26J		V25,26R		5bSKJ		5bSKR		T1SVJ		T1SVR		panel volné vazby 80 363b								
	NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000										
	01	D1 *	02		03	D1 *	04		05	D1 *	06		07	D1 *	08										
11	V14,16J		V14,16R		V22-24J		V22-24R		1aKJ		1aKR		V27J		V27R		panel volné vazby 80 363d								
	NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000										
	01	D1 *	02		03	D1 *	04		05	D1 *	06		07	D1 *	08										
10	F/C2x2A	F/C1x2A	F/C1x2A	F/C1x2A																				panel jističů a RC 80 366b	
	01	02	03	04																					
09																									
08	1bKJ		1bKR		V28J		V28R		3K-V17,21P		V15-T1P		V14-28P		panel volné vazby 80 363b										
	NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000									NMS1-2000			
	01	D1 *	02		03	D1 *	04		05	D1 *	06	D1 *	07	D1 *								08			
07	L1TJ		L1TJQ		PnLT		PnSOT		PnSOT1		PnLOT		PnLOT1		E3PHS		panel volné vazby 80 363b								
	NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000										
	01		02		03		04		05		06		07		08										
06	E3Z		E3KZ		E3BA		E3BV		E3VS		E3PR		E3ZDK		panel volné vazby 80 363b										
	NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000		NMS1-2000									NMS1-2000			
	01		02		03		04		05		06		07									08			
05																									
04																									
03																									
02	1P-A01	1P-A02	6P-D01	6P-D02	6P-D03	6P-D04	6P-D05	6P-B02	21-D09	12-D06	32-D11	11-D12	13-D05	22-D09	23-D12	31-D07	33-D03	33-D12	11-D07	6P-X06	20	21	22	23	panel svorkovnic 80 356b
01																									

LEGENDA:

- D1*

D1

R1

R2

R3

R4

C1

C3

C4

C5
- 1N4007 na vinutí relé 2-3 (katoda 3)

1N4007

150R/10W

15/15W

470/15W

1K/10W

G1/63V

2M/160V

2G/40V

G1/40V

⊙ WAGO do 16mm2 (4x283-601+2x283-316+2x283-402)
ostatní šestice WAGO 280-519 (93002Ds025)

Upravil 25.11.2023 Krupa Jar