

NÁZEV	TYP	POZICE	DOTEKY A VINUTÍ JSOU NA VÝKRESE								
			VINUTÍ	1	2	3	4	5	6	7	8
V14,16J	NMŠ1-2000	53 11 01	7024	6110	6111	24					
V14,16R	NMŠ1-2000	02	7031	7024						7029	
V22-24J	NMŠ1-2000	03	7025	6111	6116	6115	26				
V22-24R	NMŠ1-2000	04	7031	7025						7029	
1aKJ	NMŠ1-2000	05	7026	26	26	26	26				
1aKR	NMŠ1-2000	06	7031	7026						7029	
V27J	NMŠ1-2000	07	7027	6118	31	3405					
V27R	NMŠ1-2000	08	7031	7027						7029	
			VINUTÍ	1	2	3	4	5	6	7	8
1bKJ	NMŠ1-2000	08 01	7028	31	3405	6119					
1bKR	NMŠ1-2000	02	7031	7028						7029	
V28J	NMŠ1-2000	03	7029	6119	3405	31					
V28R	NMŠ1-2000	04	7031	7029						7029	
3K-V17,21P	NMŠ1-2000	05	7017	7017							7030
V15-T1P	NMŠ1-2000	06	7023	7023							7030
V14-28P	NMŠ1-2000	07	7029	7029							7030
		08									
			VINUTÍ	1	2	3	4	5	6	7	8
L1TJ	NMŠ1-2000	07 01	15	15	3305		15				
L1TJQ	NMŠ1-2000	02	15		41		41				
PnLT	NMŠ1-2000	03	38b/2		38a	50					
PnSOT	NMŠ1-2000	04	38b/2	38a	38b/2	50					
PnSOT1	NMŠ1-2000	05	38b/2	38b/2	38a	50					
PnLOT	NMŠ1-2000	06	38b/2	38a	38b/2	50					
PnLOT1	NMŠ1-2000	07	38b/2	38b/2	38a	50					
E3PHS	NMŠ1-2000	08	8001		06b						
			VINUTÍ	1	2	3	4	5	6	7	8
E3KZ	NMŠ1-2000	06 01	8323						8323		8323
E3Z	NMŠ1-2000	02	8323						8323	8323	8323
E3BA	NMŠ1-2000	03	8323								8323
E3BV	NMŠ1-2000	04	8323								8323
E3VS	NMŠ1-2000	05	8323								8323
E3PR	NMŠ1-2000	06	8323								8323
E3ZDK	NMŠ1-2000	07	8313	8313	8323			8313		8313	
		08									
			VINUTÍ	1	2	3	4	5	6	7	8
		01									
		02									
		03									
		04									
		05									
		06									
		07									
		08									
			VINUTÍ	1	2	3	4	5	6	7	8
		01									
		02									
		03									
		04									
		05									
		06									
		07									
		08									
NÁZEV	TYP	POZICE	VINUTÍ	1	2	3	4	5	6	7	8

Oprava zabezpečovacího zařízení v ŽST Štramberk

PS 01 Oprava zabezpečovacího zařízení st.1

Obsazení kontaktů relé stojanu 53, patro 05 až 11

2626