

NÁZEV	TYP	POZICE	DOTEKY A VINUTÍ JSOU NA VYKRESE								
			VINUTÍ	1	2	3	4	5	6	7	8
		01									
		02									
		03									
		04									
		05									
		06									
		07									
		08									
			VINUTÍ	1	2	3	4	5	6	7	8
SPV	NMŠ1-2000	11 16 01	8311	8311					8322		
LPV	NMŠ1-2000	02	8311	8311					8322		
E3-B	NMŠ1-2000	03	8311	8311							
E3-BU	NMŠM1-1500	04	8311	8312							
PR1	NMŠ1-2000	05	2232	8323	8323		8323	8323	8313	2234	9032
POSS	NMŠ1-2000	06	2234		8321				8313		9032
DRBQ	NMŠ1-2000	07	2234	8323	8313	8323	2234	8321	8313		9032
DRB	71 972e	08	2234	2234	2234	2234		2234		2234	
			VINUTÍ	1	2	3	4	5	6	7	8
NSKZ	NMŠ1-2000	15 01	8321	8321	8321	2234	8323	8323	8321		9032
KZ	NMŠM1-1500	02	8321	8321			8323	8323	8321		9032
NS	NMŠ1-2000	03	8321	8321	8323		8323	8323			9032
TO	NMŠ1-2000	04	8313	8312	8321	8321	8323	8323	8324		9032
TZ	NMŠM1-1500	05	8313	8312							9032
TON	NMŠ1-2000	06	8313		8313		8313		8324		9032
PDK	NMŠ1-2000	07	8313	8321	8321	8312		8323		8323	9032
KZBVQ	NMŠ1-2000	08	8321	8001	8001	8001	8001				
			VINUTÍ	1	2	3	4	5	6	7	8
A,B/A-BRS	NMŠ1-0,25/0,7	14 01	8314	8315	8318	8321					9032
B-RS	NMŠ1-0,25/0,7	02	8314	8316		8321					
A-RSH	NMŠM1-1500	03	8315	8315	8315	8315	8321	8321			9032
B-RSH	NMŠM1-1500	04	8316	8316	8316	8316	8321	8321			9032
A,B-BSH	NMŠM2-3500	05	8318		8318		8318		8318		8321
OSRQ1	NMŠ1-2000	06	8312	8315	8315	8315	8315	8315	8321	8321	8323
OSRQ2	NMŠ1-2000	07	8312	8316	8316	8316	8316	8316	8313	8321	8323
SPQ1	NMŠ1-2000	08	8313	8318	8318	8318	8318	8318	8318	8319	8319
			VINUTÍ	1	2	3	4	5	6	7	8
SR	NMŠM1-1500	13 01	8312	8312	8312	8311	8320	8321	8321		9032
C-BRS	NMŠ1-0,25/0,7	02	8314	8317	8319	8321					9032
C-RSH	NMŠM1-1500	03	8317	8317	8317	8317	8321	8321			9032
C-BSH	NMŠM2-3500	04	8319		8319				8319		8321
SP	NMŠ1-2000	05	8313	8313	8314	8314	8324	8319	8319	8321	9032
SO	NMŠ2-4000	06	8314		8314		8313		8314		9032
SOQ1	NMŠ1-2000	07	8314	8315	8315	8316	8316	8317	8317	8321	
OSRQ3	NMŠ1-2000	08	8312	8317	8317	8317	8317	8317	8313	8321	8323
			VINUTÍ	1	2	3	4	5	6	7	8
AJ	NMŠM1-1500	12 01	8311	8311	8311	8312	8313	8321		8311	8311
BJ	NMŠM1-1500	02	8311	8311	8311	8312	8313	8321	8321	8311	8311
AS	NMŠM1-1500	03	8311	8311	8322	8312	8311	8321		8311	8311
BS	NMŠM1-1500	04	8311	8311	8322	8312	8311	8321		8311	8311
X	NMŠ1-2000	05	8311			8311	8311	8321	8322	2234	
D	NMŠ1-2000	06	8311	8311	8311	8312	8311	8321	8322		9032
PB5SQ	NMŠ1-2000	07	8311		8311		8321		8311		
PB6LQ	NMŠ1-2000	08	8311		8311		8321		8311		
NÁZEV	TYP	POZICE	VINUTÍ	1	2	3	4	5	6	7	8

Oprava PZS P7491 v km 18,628 na trati Studénka-Veřovice

PS 01 PZS v km 18,628 (P7491)

Obsazení kontaktů relé, patra 12 až 16

2631

NÁZEV	TYP	POZICE	DOTEKY A VINUTÍ JSOU NA VYKRESE								
			VINUTÍ	1	2	3	4	5	6	7	8
		11 09 33									
		34									
		35									
		36									
SBPN	Schrack RT 424 024	37	8324	8324							
PR3	Schrack PT 570 024	38	2232	8323	8323	8321	9032				
POST	Schrack RT 424 024	39	2234	8321	9032						
PCJ	Schrack PT 570 024	40	8322	8323	8323		9032				
			VINUTÍ	1	2	3	4	5	6	7	8
DI	NMŠ1-2000	07 01	8311	8323	8001	8323	8001				
OSRQ4	NMŠ1-2000	02	8312	8324						8321	8323
		03									
		04									
		05									
		06									
		07									
		08									
			VINUTÍ	1	2	3	4	5	6	7	8
		01									
		02									
		03									
		04									
		05									
		06									
		07									
		08									
			VINUTÍ	1	2	3	4	5	6	7	8
		01									
		02									
		03									
		04									
		05									
		06									
		07									
		08									
			VINUTÍ	1	2	3	4	5	6	7	8
		01									
		02									
		03									
		04									
		05									
		06									
		07									
		08									
			VINUTÍ	1	2	3	4	5	6	7	8
		01									
		02									
		03									
		04									
		05									
		06									
		07									
		08									
			VINUTÍ	1	2	3	4	5	6	7	8
		01									
		02									
		03									
		04									
		05									
		06									
		07									
		08									

<b>Oprava PZS P7491 v km 18,628 na trati Studénka-Veřovice</b>	
PS 01 PZS v km 18,628 (P7491)	<b>2632</b>
Obsazení kontaktů relé, patro 07, 08, 12	