

		V.Č.
01	TI01 - 61	
02	TI01 - 62	
03	- 0 / TI02 - 11 TI01 - 11	
04	TI01 - 12	
05	TI01 - 53	
06	TI01 - 1	
07	PPN- Ć - 2	3/2
08	TI VZPL- 11	
09	TI RPN- 12	3/2
10	TI RPN- 32	3/2
11		
12		

		V.Č.
01	PI L- Z- 1	
02	L- Ć - 1	
03	po Ć, Se1 - 1	
04	TI18- 43	
05	TI18- 12	
06		
07	TI Se1 - 12	
08	Se1 - B- 1	
09	BS- Z- 2	3/2
10	TI AP- 12	
11	TI AP- 43	
12	AP- B- 1	

		V.Č.
01	LK1- B- 1/ C0601	
02	LK1- Ć - 1/ C0602	
03	LK2- B- 1	
04	LK2- Ć - 1	
05	BS- Z- 1	3/2
06	L- B- 1	
07	L- Z- 1	
08	L- Z- 1	
09	TI PS- 12	3/2
10	TI PS- 32	3/2
11	TI NS- 12	3/2
12	TI NS- 32	3/2

		V.Č.
01	C0101	
02	C0102	
03	C0103	
04	C0104	
05	C0105	
06	C0106	
07	C0107	
08	C0108	
09		
10		
11	SPB/C0111	
12	SMB/C0112	

		V.Č.
01	TI TZ- 13	8214
02	TI TZ- 33	8214
03	TI TO- 12	8214
04	TI TO- 32	8214
05	TI RPN- 12	8214
06	TI RPN- 32	8214
07	C1- Ć - 1	8214
08	C2- Ć - 1	8214
09	C3- Ć - 1	8214
10	REZ- B	8214
11	REZ- R	8214
12	REZ- B	8214

		V.Č.
01		
02		
03		
04		
05		
06		
07		
08		
09		
10		
11		
12		

		V.Č.
01	PnL po Ć - 1	
02	TI PnL- 11	
03	TI PnL- 12	
04	PS- Ć - 2	3/2
05	ZV- 2	3/2
06	PN- Ž- 2	3/2
07	AS- B- 2	3/2
08	VS- B- 2	3/2
09	L- 2TU- B- 1	
10	L- 2TU- Ć - 1	
11	L- 1TU- B- 1	
12	L- 1TU- Ć - 1	

		V.Č.
01	TI TZ- 11	3/2
02	TI TZ- 33	3/2
03	TI TO- 12	3/2
04	TI TO- 32	3/2
05	TR6- B- 4	
06	D15- 1	
07		
08	BAS- M- 1	8013
09	PN- Ž- 1	8013
10	BVS- B- 1	8013
11		
12		

		V.Č.
01	TI VZ- 12	
02	TI VZ- 32	
03	VZ- Ć - 1	
04	PI S- Ć - 1	
05	ZV PIS- 1	
06	ZV PIS- 11	
07		
08		
09		
10		
11		
12		

		V.Č.
01	SZ- TB/ C0201	
02	C0202	
03		
04		
05		
06		
07		
08		
09	NS- Ž- 2	3/2
10	NS- Ž- 1	3/2
11	KZ L1 - L3	
12	KZ L1 - L3	

		V.Č.
01	REZ- R	8214
02	BS- Z- 1	8213
03	NS- Ž- 1	8213
04	PS- Ć - 1	8213
05	PU- B- 1	8213
06	BAS- M- 1	8213
07	BVS- B- 1	8213
08	PN- Ž- 1	8213
09	TI PS- 12	8213
10	TI PS- 13	8213
11	TI NS- 12	8213
12	TI NS- 13	8213

		V.Č.
01		
02		
03		
04		
05		
06		
07		
08		
09		
10		
11		
12		

		V.Č.
01	SZ1 / A0401 (SZ)	
02	A0402	
03	A0403(SZ)	
04	A0404	
05	A0405(SZ)	
06	A0406	
07	A0407(SZ)	
08	A0408	
09		
10		
11	A0411(SPB- 1) +	
12	A0412(SMB- 1) -	

		V.Č.
01	SZ- TB/ B0401	
02	B0402	
03		
04		
05		
06		
07		
08		
09		
10		
11		
12		

		V.Č.
01	- 0	
02		
03		
04		
05		
06		
07		
08		
09		
10		
11	C0602	
12	C0601	

		V.Č.
01		
02		
03		
04		
05		
06		
07		
08		
09		
10		
11		
12		

		V.Č.
01	PPN- Ć - 1	8213
02	BS- Z- 1	8013
03	NS- Ž- 1	8013
04	PS- Ć - 1	8013
05	PU- B- 1	8013
06	TI PS- 12	8013
07	TI PS- 13	8013
08	TI NS- 12	8013
09	TI NS- 13	8013
10		
11		
12		

		V.Č.
01	A0301 / C0312	
02	A0302 / C0311	
03		
04		
05		
06		
07		
08		
09		
10		
11		
12		

NAV/RHL

KRESIL

KONTROLOVAL

SCHWALL

AUTOMATIZACE
ZELEZNIČNÍ
DOPRAVY
PRAHA

PS. 01. ZAB. ZAŘIZENÍ RELEOVÉ
SVORKOVNICE ŘÍDICIHO STOLU P1

KUNOVICE - LOUČKA RZZ

A4

2

DATUM

1.2015

01 45 01 75 01

5 / 4

OLOMOUČ

Č. KOPIE