



číslo	souřadnice X	souřadnice Y
01	-788133.45	-1122679.9
02	-788463.52	-1122748.3
03	-788484.95	-1122753.8
04	-788486.26	-1122749.0
05	-788510.15	-1122756.8
06	-788517.06	-1122760.0
07	-788517.07	-1122758.2
08	-788518.31	-1122752.0
09	-788515.48	-1122751.4
10	-788516.09	-1122748.4
11	-788523.93	-1122750.1
12	-788523.32	-1122753.0
13	-788524.48	-1122760.6
14	-788526.63	-1122761.0
15	-788524.91	-1122769.3
16	-788525.99	-1122769.6
17	-788541.67	-1122761.0
18	-788545.63	-1122765.5
19	-788545.28	-1122766.8
20	-788564.90	-1122769.3

21	-788605.93	-1122780.
22	-788628.05	-1122788.
23	-788630.87	-1122787.
24	-788633.67	-1122788.
25	-788634.90	-1122790.
26	-788654.01	-1122797.
27	-788674.96	-1122807.
28	-788678.80	-1122805.
29	-788682.05	-1122807.
30	-788683.62	-1122811.
31	-788771.19	-1122851.
32	-788769.96	-1122853.
33	-788836.47	-1122880.
34	-788885.59	-1122897.
35	-788915.32	-1122911.
36	-788946.13	-1122916.
37	-789043.29	-1122946.
38	-789127.68	-1122972.
39	-789212.66	-1122998.
40	-789233.33	-1123004.

└ Strakonice ─▶

